

Hookah Maintenance

MAINTAINING YOUR HOOKAH



Please remove the Ceramic Bowl and Hookah Tray from the top portion of your Hookah. Be sure to remove the Bowl Grommet from the shaft as well.



Close off the bottom and top openings of the Shaft and then shake the Shaft in your hands for up to 30 seconds to distribute the solution evenly.



Using warm water, rinse out the Ceramic Bowl, Hookah Tray, Rubber Grommets, Shaft, and Vase in a thorough manner.



Using the Cleaning Brushes provided with your Hookah, take one Cleaning Brush and insert it into the top opening of the Shaft, rotating the brush in a clockwise fashion.



Next, gather your Cleaning Brushes, SouthSmoke.com approved Hookah Cleaning Solution, and a towel to finish the cleaning process. Remember not to use any type of soap when cleaning your Hookah.



Using warm water, rise the Shaft thoroughly.



Now, shake the Hookah Cleaning Solution, and dispense a small amount of the solution into the Shaft, making sure that the bottom opening of the shaft is closed off with your finger. This will allow for any buildup and Shisha particles to be loosened for proper cleaning.



Repeat the same cleaning process for the Vase, Hookah Hose, and Ceramic Bowl. Only use warm water when cleaning the Rubber Grommets.



Finally, dry off each piece of the Hookah using a towel and then re-assemble the Hookah for storing or display purposes.